

MAP Type

illustration image

The MIREL MAP software operates as manager of MIREL applications on PC or notebook. It consists of main control module and executive modules. The control module, inseparable part of created work station, controls start, control and security of executive modules. Executive modules are optional modules and they perform specific support activities for MIREL systems operation and maintenance.

Requirements on program and technical equipment for installed executive modules have been specified in respective documentation.

Detailed configuration of MIREL MAP program equipment is provided based on software equipment questionnaire sent by HMH s.r.o. Company, along with installation medium for the purpose of new license implementation or supplement of an existing one, which is then completed by the Customer and sent back.



Modifications

Designation	KAM	KAM3G	MAN	MSPKAL	SID	SpeedMeter	T350	Test3G	TransWin	TSM3G	TZJ	VZTUI
MAP.1.D3	-	-	-	-	yes	-	-	yes	-	-	-	yes
MAP.1.S1A	yes	-	-	-	yes	-	-	-	-	-	-	yes
MAP.1.S1B	yes	yes	yes	-	yes	yes	-	yes	yes	yes	-	yes
MAP.1.S1C	yes	yes	yes	yes	yes	yes	-	yes	yes	yes	-	yes
MAP.1.S1D	yes	yes	yes	yes	yes	yes	yes	yes	yes	yes	-	yes
MAP.1.INTA	yes	-	-	-	yes	-	-	-	-	-	yes	yes
MAP.1.INTB	yes	yes	yes	-	yes	yes	-	yes	yes	yes	yes	yes
MAP.1.INSF	-	-	yes	-	-	yes	-	-	-	-	-	-
MAP.1.KON	-	-	yes	-	-	yes	-	-	yes	-	-	-

yes module enabled, permission to execute
 - module disabled

List of MIREL MAP Executive Modules

- KAM Configuration of MIREL systems 2G
- KAM3G Configuration of MIREL systems 3G
- MAN Visualization of registered data of MIREL systems from SD-card entries
- MSPKAL MIREL MSP Calibrator
- SID Identification of MIREL device software
- SpeedMeter Evaluation and archiving workplace MIREL ARKTUR
- T350 Testing of MIREL system RS350
- Test3G Testing of MIREL systems 3G
- TransWin Evaluation and archiving of data from MIREL RMI1 and MIREL BB (workplace MIREL ARKTUR)
- TSM3G Visualization of MIREL 3G systems
- TZJ Control for test device of MIREL TZJU basic units
- VZTUI Control MIREL VZT.4

Specifications

No.	Version	Title
974MAP	190205	MIREL MAP User Manual
975MAP	190205	MIREL MAP Installation Manual
415RM1	000000	ARKTUR Operating Instructions
547MAP	191217	MIREL KAM User Manual_v03
851MSP	000000	MSPKAL Operating Instructions
1442TZJU	171114	TZJU Operating Instructions
1728M	190226	MIREL Software Equipment Questionnaire
1783MAP	180116	MIRELTest3G User manual
2309MAP	170616	TSM3G User manual
2418MAP	191108	VZTUI User manual
2658MAP	191126	MAN v02 User Manual